# DA-ML

# DALI

CE RoHS

# **RF DALI Dimmer**


- RF signal input, DALI signal output.
- Can be used as a DALI bus power supply.
- 1 DALI address, support DT6 dimming, DT8-TC color temperature, DT8-RGB, DT8-RGBW or DT7 switch.
- In accordance with DALI standard protocol IEC 62386-101, 102, 207, 208, 209, and in compliance with DALI products from other international incorporation.
- Enable to select DALI address by encoding switch, support unicast, group and broadcast mode.
- For RGB/RGBW/RGB+CCT light type, built in 10 dynamic mode, include jump or gradual change style.
- Connect with external push switch to achieve on/off and 0-100% dimming function.
- Match with RF 2.4G single zone or multiple zone remote control optional.



# Technical Parameters


Input and Output		Environment		Safety and EMC	
Input voltage	100-240VAC	Operation temperature	Ta: -20°C ~ +55°C	EMC standard	EN IEC 55015/EN IEC 61547 ETSI EN 301 489-1/-3/-17
Input Current	O.1A	Case temperature (Max.)	Tc: +75°C	— Safety standard	EN 61347-1/-2
Output voltage	16VDC	IP rating	IP 20	— Salely slandard	
DALI output current	Max 150mA			Radio Equipment	ETSI EN 300 440 ETSI EN 300 328
Input signal	Push switch + RF 2.4GHz	Package		Certification	CE RoHs
Output signal	DALI	Size	L156x W48x H22mm	Warranty	
Control distance	30m(Barrier-free space)	Gross weight	0.085kg	Warranty	5 years

#### Mechanical Structures and Installations




# Wiring Diagram

• DA-ML as RF-DALI master:



User Manual Ver 1.0.1

• DA-ML as DALI bus power supply:



DALI LED driver: include DALI dimming controller, DALI dimming driver, etc.

Control Unit: include DALI master, self-resetting switch, DALI switch panel, DALI sensor, etc.

#### Push Dim Function

Short press: Turn on or off light.

Long press 1-6s: Step-less dimming, with every other long press, the light level goes to the opposite direction.

# Light Type Settings

Please select the light type before the remote control.

Press and hold Match/Set key for 2s, switch 6 kinds light type in sequence, and LED indicator turn corresponding color.

Light type	DIM	CCT	RGB	RGBW	RGB+CCT	SWITCH
LED indicator color	White	Yellow	Red	Green	Blue	Cyan

#### Match Remote Control

Please select the same light type of RF remote control for matching,

End user can choose the suitable match/delete ways. Two options are offered for selection:

### Use the Match key

#### Match:

Short press match key, immediately press on/off key (single zone remote) or zone key (multiple zone remote) on the remote.

The LED indicator fast flash a few times means match is successful.

#### Delete:

Press and hold match key for 5s to delete all match, The LED indicator fast flash a few times means all matched remotes were deleted.

#### Use Power Restart

#### Match:

Switch off the power of the receiver, then switch on power, repeat again. Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote. The LED indicator blinks 3 times means match is successful.

#### Delete:

Switch off the power of the receiver, then switch on power, repeat again. Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote. The LED indicator blinks 5 times means all matched remotes were deleted.

# Dynamic Change Mode List

Ten built-in dynamic modes can be called up with the remote control's mode button.

#### For RGB/RGBW:

No.	Name	No.	Name
1	RGB jump	6	RGB fade in and out
2	RGB smooth	7	Red fade in and out
3	6 color jump	8	Green fade in and out
4	6 color smooth	9	Blue fade in and out
5	Yellow cyan purple smooth	10	White fade in and out

#### For RGB+CCT:


No.	Name	No.	Name
1	RGB jump	6	RGB fade in and out
2	RGB smooth	7	Red fade in and out
3	6 color jump	8	Green fade in and out
4	6 color smooth	9	Blue fade in and out
5	Color temperature smooth	10	White fade in and out

# **DALI Address Setting**

Address value = X \* 10 + Y.

For example: X = 5, Y = 4, Address value =  $5 \times 10 + 4 = 54$ .

### Unicast mode






X is 0-6, Y is 0-9.

Address value 0-63 correspond to DALI unicast address 00-63.

For example:

Address value = 40, the unicast address value is 40.








X is 7, Y is O-F.

Address value 70-7F correspond to DALI group address 0-15.

For example:

Address value = 75, the group address value is 5.

Broadcast mode





X is 9, Y is 0-F.

Address value 90 - 9F correspond to broadcast address.